

# Bathroom Widespread Sink Faucet MAIDSTONE Installation Guide

1. If your faucet comes with the brass T attached to the faucet body, unthread and remove the T and associated hardware.
2. Thread the silver mounting washer on the faucet body.
3. Apply a bead of silicone sealant to the underside of the spout, or faucet base, and thread through the center mounting hole.
4. Thread the mounting hardware and brass T onto the spout pipe and hand-tighten to secure.
5. Check to make sure the faucet is properly aligned and adjust as needed. When the faucet is in the proper position, finish tightening mounting hardware with your adjustable wrench.

**Tip: Make sure that the T outlets are aligned at an angle to allow maximum clearance for water connections.**

6. Wipe away any excess sealant around the faucet base using your damp cloth.
7. Assemble the handles by screwing the lock nuts down to the end of the handle bodies. If handles are assembled move on to step 8.
8. Insert the handle bodies up through the mounting holes. Thread the plastic slip washers and rubber sealing gaskets onto the handle bodies to secure.
9. Hand tighten to attach the hot and cold flexible water feed tubes to the handle bodies and brass T. Give a  $\frac{1}{4}$  turn with pliers or wrench, but don't over tighten. (Hot water is always on the left and cold water is always on the right.) Curve tubes as necessary to ensure there are no kinks or knots.