



MAIDSTONE

# Oval Shower Curtain Rod Installation Guide

**NOTE:** As with all Maidstone products, it is recommended that a licensed plumber or contractor install this item to maintain warranty.

1. Lay oval shower rod out on floor as shown on parts sheet
2. Carefully slide support loops (OV-3) onto U-shaped enclosure rod (OV-1), careful to avoid scratching the rods. Use set screws (E-SETS CREW) to secure in desired position **NOTE:** Support rods must be spaced evenly around the oval enclosure rod to disperse the weight of the shower curtain.
3. Use compression sleeves (E-17) to connect the 2 U-shaped rods (OV-1)
4. Attach ceiling support rods (OV-4) to support loops (OV-3) and secure with set screws (E-SET SCREW)
5. Screw ceiling flanges (OV-7) onto the opposite end of each support rod (OV-4)

**NOTE:** Ceiling support rods are able to be cut shorter if necessary. Please be sure to cut the non-threaded end of the support rod.

\*\*\*THE FOLLOWING STEPS MAY REQUIRE THE HELP OF 1 OR MORE PEOPLE

6. Using the support rods (OV-4), hold the assembled shower ring to the ceiling in the desired location.
7. Using the ceiling flanges (OV-7) as a guide, mark the positioning of the mounting holes of each flange.
8. Drill pilot holes for the plastic anchor bolts (E-PLASTIC ANCHOR) in these positions.
9. Insert plastic anchor bolts (E-PLASTIC ANCHOR) into pilot holes and mount the shower enclosure to the ceiling with the flange screws (E-DRYWALL SCREW).